

# BOSS RC-500 LOOP STATION

## QUICK START GUIDE

### RECORDING A LOOP

- **Plug** guitar into INST INPUT A and amp into OUTPUT A.
- **Set up** the drum machine if required ( long press to access menu)
- **Press RHYTHM ON/OFF** button until the green light is steady to start rhythm.
- **Practice loop**, tapping foot on floor when you need to press foot switch and check sound levels and tempo.
- **Start recording** by tapping the REC/PLAY foot switch on the first beat of the bar. RED screen.
- **Stop recording and start playback** by tapping the REC/PLAY foot switch. GREEN screen.
- **Start recording again to overdub**. YELLOW screen.
- Repeat as necessary.
- **Press STOP** foot switch to take a break.
- **Long press** on STOP foot switch to **clear**.
- **Press EXIT and ENTER** together to **save** to empty memory slot.

### SCREEN COLOR

Blue	empty memory
White	used memory
Red	recording
Green	playback
Yellow	overdub

### PATTERN NAME VARIATIONS

SIMPLE BEAT 1-4
GROOVE BEAT 1-7
ROCK 1-4
FUNK 1-4
SHUFFLE 1-5
SWING 1-5
SIDE STICK 1-5
PERCUSSIVE BEAT 1-4
LATIN BEAT 1-4
CONGA 1-3
BOSSA 1-2
SAMBA 1-2
DANCE BEAT 1-4
METRONOME 1-4

### RHYTHM ON/OFF BUTTON:

**PRESS** to toggle between standby/on/off

**LONG PRESS** to access menu

### AVAILABLE KITS

STUDIO  
LIVE  
LIGHT  
HEAVY  
ROCK  
METAL  
JAZZ  
BRUSH  
CAHON  
DRUM & BASS  
R & B  
DANCE  
TECHNO  
DANCE BEATS  
HIP HOP

**SPACE FOR YOU TO NOTE DOWN YOUR FAVORITES**

